

Chevy Dashboard Symbols

Complete Reference Guide

Bomnin Chevrolet West Kendall • <https://www.bomninchvroletwestkendall.com>

Dashboard Light Color Meanings

- Red/Orange: Urgent issues requiring immediate attention
- Yellow: Cautionary alerts, service may be needed
- Green: Positive indicators, feature ready or active
- Gray: Feature on but in standby mode
- Flashing: Urgent or escalating issue

Safety and Driver Assistance Lights

Chevy's safety and driver assistance lights provide real-time alerts and information to help you stay aware of your surroundings and let you know when certain features are active. From Lane Departure Warnings to Automatic Emergency Braking indicators, these lights provide crucial information.

Lane Keep Assist

When equipped with Lane Keep Assist, your vehicle dashboard will display this symbol in green when it is active, in white when it is not active, or in orange if it detects you drifting into another lane.

Automatic Emergency Braking Disabled

If your vehicle has Automatic Emergency Braking and you see this icon that looks like a collision, don't panic. This light shows up when this feature is not active. So, if you've turned off the Automatic Emergency Braking in your vehicle settings, it's normal to see this light. It's just letting you know to pay attention because the vehicle will not brake for you when it detects a stopped or slowed vehicle ahead.

Pedestrian Ahead Indicator

The Pedestrian Ahead Indicator light, when equipped, illuminates when your vehicle has detected a pedestrian or bicyclist ahead of you. Be alert for any pedestrians when you see this light.

Adaptive Cruise Control

The Adaptive Cruise Control light shows up in white when the feature is on but not in use, and when it is green, it means it is on, in use, and maintaining a following gap between you and the vehicle ahead of you.

Super Cruise

If your vehicle is equipped with Super Cruise, this light and the steering wheel light bar will show you the status of the feature. There are many different indicators for this system, including green, blue, red, solid, flashing, and more. Refer to your owner's manual if you have the Super Cruise system to familiarize yourself with the important messages of this system.

Automatic Vehicle Hold

The 'AUTO HOLD' light illuminates in green when your AVH (if equipped) is active and holding your vehicle in place.

Lane Departure Warning

If your vehicle has a Lane Departure Warning system, you will see this symbol in green if the system is active. If it illuminates in yellow and flashes, it tells you that you crossed a lane without using your turn signal.

Forward Collision Alert Vehicle Ahead Indicator

This icon illuminates in green when the Forward Collision system is active (when equipped). If it is yellow, it's telling you that you may be tailgating the vehicle in front of you or following them too closely.

Cruise Control

The Cruise Control icon looks like a speed limit gauge. This icon illuminates in white when Cruise Control is active but not in use, and it illuminates in green when Cruise Control is on and you have set a speed limit.

Adaptive Cruise Control Curve Speed Control

The ACC Curve Speed Control light illuminates in green to tell you that it is actively controlling your speed and detects a sharp curve in the road. This feature automatically slows your vehicle down while going through the curve.

Driver Attention Assist

A drowsy-looking eye symbol or a coffee cup icon illuminates Chevy vehicles with Driver Attention Assist to let you know if it detects drowsy driving. A Level 1 warning is a yellow icon in your display cluster, which means you are tired and should do something to increase your alertness, like rolling down a window or playing music. A Level 2 warning is a red coffee cup icon that indicates severe exhaustion and that you may be drifting in and out of sleep. It is paired with several chimes and/or Safety Alert seat pulses.

Engine and Battery Warning Symbols

Your vehicle's engine and battery warning lights signal when something may need attention under the hood. Whether it's the Check Engine Light, Oil Pressure Warning, or Low Fuel Indicator, these lights illuminate to tell you important information about your vehicle's functioning.

Check Engine

The Check Engine light will illuminate when your vehicle has detected a malfunction somewhere within the engine or the propulsion system. If you have an electric vehicle, you may see this light associated with charging issues. When you see this light, be sure to have your vehicle serviced as soon as possible.

Service Vehicle

This light appears as a car with an exclamation point and is telling you that there is potentially a problem with your vehicle battery or propulsion system. It's recommended to get your vehicle into a Certified Chevy service center as soon as possible if you see this light.

Engine Coolant Temperature Warning

This light will appear when you first start your vehicle, and it will shut off shortly. If it doesn't shut off, you will need to have your vehicle serviced immediately. If this light illuminates while driving, it indicates that your vehicle is overheating. Pull over immediately, turn the vehicle off, and plan for it to be towed to a service center to avoid further engine damage.

Engine Oil Pressure

This is another light that turns on when you first start your vehicle but turns off quickly. If it comes on while you're driving, you should pull over and turn off the engine as soon as it is safe to do so. Check your oil and add more if the level is low, or have your vehicle taken to a service center ASAP.

Low Fuel Warning

This light indicates that you have low fuel, and it is another indicator that shows up briefly when you first start your vehicle.

Charging System Indicator

This light shows a battery and it lights up when you first start your vehicle, then shuts off. If it stays on or turns on while driving, it means there could be an issue with the electrical system in your Chevy vehicle.

Charge Cord Connected Light

This light powers on when a charging cord is connected to your EV.

Battery Fault Indicator

The Battery Fault Indicator light shows up when your vehicle has detected a problem with the battery system. If you see this, take your vehicle in for service immediately.

Low State of Charge

This battery-shaped indicator light shows if your electric vehicle is low on charge and should turn off once you charge it.

Propulsion Power Limited

This turtle-shaped icon shows up if your vehicle has detected an issue with the propulsion system, and you may not be able to fully accelerate. If you see this light, schedule Chevrolet service immediately.

Chevy Driving Warning Lights

Driving warning lights help monitor the performance and stability of your vehicle. From the Brake System light to the Tire Pressure Warning or Traction Control System indicator, these lights let you know what systems are working or need attention.

Brake System

The brake light illuminates and flashes when you first start your vehicle. If it stays on, there may be an issue with your brakes. It can also show up if you have low brake fluid levels. If it stays on, schedule service ASAP.

Electric Parking Brake

When your electric parking brake is activated, you'll see a solid 'PARK' light on your Chevrolet dashboard cluster.

Service Electric Parking Brake

A 'P' in a circle with a wrench is an indicator that your vehicle's electric parking brake needs service. It will flash when you first start your vehicle to let you know it's working, but if this light remains illuminated, schedule service ASAP.

Hill Descent Control

This light shows up as a green car symbol on the dashboard. Chevy vehicles equipped with Hill Descent Control use this feature to control your speed on hills. If it's green and flashing, that means it is active and working.

Antilock Brake System

This ABS light flashes when you start your vehicle. If it comes on while driving, it indicates that there may be an issue with your Antilock Brake System, so you should schedule service ASAP.

Traction Off Light

The Traction Off light also flashes when you start your vehicle. However, if it remains on or turns on while driving, it means that the Traction Control System is turned off. You can turn it back on through the infotainment system.

Electronic Stability Control Off

This symbol shows you that the Electronic Stability Control system is turned off.

Trailer Sway Control

When equipped, the Trailer Sway Control light comes on when the feature is active.

Security Light

The Security Light will flash when you start your vehicle (if equipped) with a theft-deterrent system. If you don't see it, you may need to contact your dealer for service.

Tire Pressure Light

This light will flash when you start your vehicle, but it will illuminate when one or more of your tires have, but it will also indicate tire pressure.

Fully Lowered

This symbol shows you that your vehicle is fully lowered.

Vehicle Ready Light

This green light is there to let you know that your vehicle is ready to drive!

Door Ajar

This light tells you that one or more doors are open or partially open.

Normal Drive Mode

This mode is for normal driving.

Vehicle Feature Warning Symbols

Chevy vehicles include various feature-related warning symbols that provide information about your car's special capabilities. From customizable drive modes to four-wheel drive systems, you may see some of these indicators when utilizing certain features of your vehicle.

Four-Wheel Drive Light

If equipped, this light shows up when you are using four-wheel drive.

Electric Parking Brake

When your electric parking brake is activated, you'll see a solid 'PARK' light on your Chevrolet dashboard cluster.

Sport Drive Mode

This mode provides a more responsive driving experience.

Hill Descent Control

This light shows up as a green car symbol on the dashboard. Chevy vehicles equipped with Hill Descent Control use this feature to control your speed on hills. If it's green and flashing, that means it is active and working.

Terrain Drive Mode

This mode is designed for mild off-road driving.

Traction Off Light

The Traction Off light also flashes when you start your vehicle. However, if it remains on or turns on while driving, it means that the Traction Control System is turned off. You can turn it back on through the infotainment system.

Tow/Haul Drive Mode

Use this mode when pulling a trailer or hauling a heavy load.

Trailer Sway Control

When equipped, the Trailer Sway Control light comes on when the feature is active.

Wide Open Watts

When equipped, this light turns on when your EV is in Wide Open Watts mode, giving you additional power and torque from your battery, giving you additional horsepower.

Tire Pressure Light

This light will flash when you start your vehicle, but it will illuminate when one or more of your tires have, but it will also indicate tire pressure.

Maximum Height

This icon signifies that your vehicle is at maximum height.

Vehicle Ready Light

This green light is there to let you know that your vehicle is ready to drive!

Fully Lowered

This symbol shows you that your vehicle is fully lowered.

Normal Drive Mode

This mode is for normal driving.

Service or Alignment Mode

This icon tells you when the ride suspension of your vehicle is in Service Mode or Alignment Mode.

Snow Drive Mode

Snow mode enhances performance in snowy conditions.

Door Ajar

This light tells you that one or more doors are open or partially open.

Off-Road Drive Mode

Off-road mode is for true off-roading.

My Drive Mode

This is a customizable mode you can edit in your infotainment system for your specific driving preferences.

Four-Wheel Steering

If your Chevy has four-wheel steering, this light turns on if you've turned the rear-wheel steering off.

Raising Height

This icon indicates that your vehicle is raised above its normal height. If it is green, it means the automobile is actively raising.

Lowering Height

This light appears when the vehicle has lowered its height. If the light is green, it means the car is actively lowering.

Important:

This guide covers common dashboard symbols. Always consult your owner's manual for complete information.

For service appointments or questions, contact www.bomninchvroletwestkendall.com

Call Us | Service

(305) 340-2550

Located at 11701 SW 152nd St, Miami, FL 33177 [Get Directions](#)

Get Directions

Get Directions</